



Water

GWF

GWF4D technology®

SONICO® EDGE

ULTRASONIC FLOW METER



Manual

Rev. N 01/2024

Revision History

This version of the document replaces all previous versions.

Rev.No.	Date	Comment
01/2020	06.01.2020	1. release
05/2021	03.05.2021	2. release
12/2021	03.12.2021	3. release
03/2023	01.03.2023	4. release
08/2023	11.08.2023	5. release
09/2023	31.08.2023	6. release
01/2024	12.01.2024	7. release

Copyright® 2024 GWF AG

Text, illustrations and tables were compiled with largest care. Nevertheless, GWF AG can take neither a Legal responsibility nor any liability for possibly remaining incorrect data and their consequences. All rights reserved. No part of this documentation may be reproduced in any form, stored or transferred, neither electronically, mechanically, photo-technically, by recording on data media, still otherwise, as long as no expressly written authorization of the publisher is present. The use of the software or the associated material without license leads to claims for damages and fines. GWF AG assumes no liability for products or software described in this document and resulting damages. We reserve the right to change the described products without prior notice. This publication can be updated and modified without prior notice.

GWF AG

Obergrundstrasse 119
6005 Lucerne, Switzerland

T +41 41 319 50 50
www.gwf.ch

Table of contents

TABLE OF CONTENTS	1
LIST OF FIGURES	2
LIST OF TABLES	3
TAKING OFF – GENERAL INFORMATION	4
1 ABOUT THIS DOCUMENT	5
1.1 Copyright	5
1.2 Data protection and security	5
1.3 Liability	5
1.4 Warnings and safety symbols	6
1.5 Trademarks	6
2 BASIC SAFETY INSTRUCTIONS	7
2.1 Requirements for personnel	7
2.2 Designated use	7
2.3 Workplace safety	7
2.4 Operational safety	7
2.5 Product safety	8
2.6 IT security	8
3 PRODUCT DESCRIPTION	9
3.1 Product dimensions	9
3.2 Product design	10
3.3 Seals	10
3.4 Applications	11
3.5 4D technology®	12
4 INCOMING INSPECTION	14
4.1 Scope of delivery	14
4.2 Checklist incoming acceptance	15
4.3 Nameplate	16
5 STORAGE / TRANSPORT	17
5.1 Storage	17
5.2 Transport	17
5.3 Packaging disposal	17
GETTING STARTED – INSTALLATION AND MOUNTING	18
6 INSTALLATION / MOUNTING	19
6.1 General requirements	19
6.2 Installation conditions	19
6.3 Environment and process requirements	21
6.4 Checklist installation preparation	21
6.5 Mounting	21
6.5.1 Torques and pressures	22
7 ELECTRICAL CONNECTION	23
7.1 Checklist electrical connection: tools and requirements	23
7.2 Power supply meter	23
7.2.1 Technical specification for power transformer	23
7.2.2 Power cable and joint connection	24
7.3 Checklist electrical connection: final inspection	24
8 DISPLAY AND METER ACTIVATION	25
8.1 Display symbols	25
8.2 Meter activation	26

8.3	Default display sequence	27
8.4	Test bench mode	29
ALL THINGS SOFTWARE – IR INTERFACE AND COMMUNICATION		30
9	IR INTERFACE (OPTOHEAD) AND SONICO® LIFE APPLICATION	31
9.1	Activation of IR interface	31
9.2	Sonico® LIFE to enable legal meter information.....	32
9.3	Removal of optohead.....	33
10	COMMUNICATION MODULES.....	34
10.1	Exchanging or adding communication modules.....	34
HOUSTON, WE HAVE A PROBLEM – ALARMS AND TROUBLESHOOTING		38
11	ERROR CODES AND TROUBLESHOOTING	39
WE'RE ALMOST DONE – AFTER USE AND DETAILS		41
12	DISMOUNTING AND DISPOSAL.....	42
12.1	Dismounting.....	42
12.2	Disposal.....	42
12.3	Recycling.....	42
12.3.1	Product recycling and disposal (Europe only).....	42
12.4	Return / Repair.....	43
13	TECHNICAL DATA AND CERTIFICATION	44
13.1	Metrological data	44
13.2	Environmental specifications and certification	44
14	SPARE PARTS AND ACCESSORIES	45
14.1	Available accessories.....	45
14.2	Communication modules	45
14.3	Spare parts.....	45
15	ANNEX	46
15.1	Checklists.....	46
15.1.1	Checklist incoming acceptance ←	46
15.1.2	Checklist installation preparation ←	47
15.1.3	Checklist electrical connection: tools and requirements ←	47
15.1.4	Checklist electrical connection: final inspection ←.....	47
16	NOTICES	48

List of figures

Figure 1: Dimensions of sonico® EDGE with (right) and without (middle) external NFC modules.....	9
Figure 2: Calibration seal.....	10
Figure 3: Meter cap as seal for electronics.....	11
Figure 4: Communication seal for modules.....	11
Figure 5: Illustration of time of flight measurement principle	12
Figure 6: Ultrasonic pulse sent in standing water.....	12
Figure 7: Meter-specific base signal received in standing water	12
Figure 8: Time-reversed base signal forms the TRA reference signal.....	13
Figure 9: Every sonico® EDGE meter has an individual TRA signal.....	13
Figure 10: The reference signals received with and against flow direction are overlapped.....	13
Figure 11: Scope of delivery	14
Figure 12: Optional accessories.....	15
Figure 13: Exemplary name plate (DN50 meter)	16
Figure 14: Lifting instructions.....	17
Figure 15: Schematic illustration of bolt tightening to flanges.....	22

Figure 16: Electrical connection scheme and part list of sonico® EDGE meter power supply	24
Figure 17: Scheme of all segments visible on sonico® EDGE display	25
Figure 18: Standard display of volume with three decimals.....	26
Figure 19: Exemplary screenshot of forward flow volume register as shown in display sequence.....	27
Figure 20: Exemplary screenshot of back flow volume register as shown in display sequence.....	28
Figure 21: Example of display during activated test bench mode.	29
Figure 22: Optohead (IR to Bluetooth)	31
Figure 23: Connecting the optohead in the holding cover to the meter	31
Figure 24: Optohead fitted on the meter. Display lid is in a 90° angle to the meter display.....	32
Figure 25: Removal of optohead cover by pushing back display lid	33
Figure 32: Breaking of communication seal and lifting of module lid.....	34
Figure 33: Exchanging protective cover in order to add a new module	35
Figure 34: Inserting module, pushing it into place and closing the module lid.....	36

List of tables

Table 1: Dimensions of sonico® EDGE meters.....	9
Table 2: Recommended torque values	22
Table 3: Symbols of the sonico® display.....	25
Table 4: Connection schematics communication modules.....	37
Table 5: Error types and codes and their standard thresholds	40
Table 6: Metrological data of sonico® EDGE flow meters.....	44



Taking Off – General Information

1 About this document

This user manual provides all necessary information for the operation and the efficient and safe use of the **sonico® EDGE** flow meter. It contains important information on product identification, storage, installation, commissioning, operation, maintenance and disposal. Before putting the device into operation, read this user manual carefully. Failure to follow the instructions and safety precautions may result in serious injury or damage to the instrument. Use the device only for the intended use described below. Keep this manual in a safe location for future reference. If you do not understand the contents of this document, contact the manufacturer. In no case may GWF be held liable for any damage or injury caused by misunderstanding of the information.

1.1 Copyright

All rights reserved. The contents and works in this document are subject to Swiss laws. Contributions from third parties are identified as such. No part of this manual may be reproduced in any form (print, photocopy, microfilm or any other process) or processed, duplicated or distributed using electronic systems without the expressly written authorization from GWF.

1.2 Data protection and security

All data should be backed-up prior to the installation of any peripheral storage device. GWF will not be responsible for any loss of data resulting from the use or misuse of this or any other GWF product. GWF is ISO 27001 certified. Data security is given by personated login with username and password. Data will be saved on server with appropriate security measures to ensure protection against data loss, data abuse and unauthorized data modifications.

Please be advised that there are inherent security risks in transmitting data via the internet. It is not possible to safeguard completely against unauthorized access by third parties.





The use of contact data published within the framework of the imprint obligation by third parties for the transmission of not expressly requested advertising and information material is hereby explicitly rejected.

1.3 Liability

In case of inappropriate or unintended use, no liability for the proper function of the device can be assumed. Improper installation and operation of the device will cause the warranty to be void. GWF has made every effort to ensure the accuracy of the contents of this manual and the software. However, GWF can offer no guarantee that the information provided is accurate and/or free of error. The information provided in this manual is subject to change without notice at any time. GWF reserves the right to alter designs, layouts or software without prior notification and will not be liable in any way for possible consequences of such changes.

1.4 Warnings and safety symbols

Depending on the hazard level, warnings are indicated as follows.

	Warning High risk. Indicates a potentially or imminently hazardous situation which, if not avoided, can result in serious injury or even death.
	Caution Minor risk. Indicates a potentially hazardous situation that could result in minor or moderate injury or damage to the device or to parts of the operator's plant.
	Notice Important handling instruction. Indicates a situation which, if not avoided, may cause damage to the device or to parts of the operator's plant. Information that requires special emphasis.
	Information This symbol indicates helpful notes and information for handling the device.

1.5 Trademarks

All terms and brand names used in the manual are generally subject to the trade mark and patent protection of the respective companies.

2 Basic safety instructions

2.1 Requirements for personnel

Installation, electrical connections, commissioning, operation and maintenance of the device must be carried out by qualified, specially trained and authorized personnel. The following requirements must be met:

- The user manual must be read carefully and fully understood by qualified personnel before starting installation. Instructions must be followed.
- Qualified personnel must be authorized by the plant operator.
- Personnel must be familiar with local or national regulations.

2.2 Designated use



Caution

Improper use can seriously compromise the safety of the device. The device is exclusively designed to be used for purposes as described below.
Keep within the specified pressure and temperature range while using the device.



Information

The manufacturer is not liable for any damage resulting from improper use or use deviating from the intended purpose.

The ultrasonic flow meter **sonico**® EDGE is designed for measurement of flow velocity and net volume flow of clean cold water in fully filled pipes.

The meter is only intended for use within the technical limit values specified in chapter **13.1** of this manual or in the data sheets.

2.3 Workplace safety

During work on and with the device the required personal protective equipment must always be worn. All applicable national and local standards, safety requirements and accident prevention regulations must be observed.

2.4 Operational safety

The operator is responsible for interference-free operation of the device:

- Operate the device in proper technical and fail-safe condition only.
- Observe handling and lifting instructions to avoid damage or injury.
- Unauthorized modifications to the device are prohibited and may result in unforeseeable dangers.

2.5 Product safety

This product has been tested extensively and left the factory in a condition in which it is safe to use. The device meets general safety standards and legal requirements. Sonico® EDGE complies with the EU directives listed in the corresponding EU Declaration of Conformity.



Warning

This product contains a lithium-ion back-up battery. Incorrect use or operation of the battery may result in potentially serious hazards.

Only batteries approved by GWF may be installed within sonico® EDGE devices. Repairs and replacements are only to be done by trained GWF professionals.

Do not expose the meter to temperatures above 70 °C.

Do not ship or transport sonico® EDGE unless the following instructions are followed:

The built-in lithium-ion batteries are classified as 'category UN3481 PI 967 Sec II'. The transport of devices containing such batteries must conform to the applicable rules specific to the means of transport used. Regulations on packing, identification and accompanying documents must be followed. The carrier must always be informed of the contents. A suitable warning label according to 'UN3481 PI 967 Sec II' must be attached to the packing and remain visible on the outside of the package.

Do not dispose of depleted or partially depleted batteries. Batteries must be transported and recycled conforming to local regulations. According to European regulations (EU Directive 2012/19/EU), European old or end-of-life equipment may be returned to the manufacturer for disposal or recycling.

Damaged, leaking or overheated batteries must be handled by a specialist. All personnel must immediately be evacuated from the area and professional assistance must be provided.

2.6 IT security

Warranties are valid only if the device is installed and used as described in this manual. Security mechanisms are implemented in sonico® EDGE to prevent crucial settings from tampering or inadvertent changes as according to WELMEC 7.2.

Additional IT security measures for the device and data transfer must be implemented by the operators themselves according to their security standards.

3 Product description

Sonico® EDGE is an externally powered precision flow meter suitable for flow measurement of cold water in fully filled pipes. Its measurement method is based on the ultrasonic time of flight principle. Due to its advanced signal processing applying the methods of Time Reversed Acoustics, sonico® EDGE is known as a GWF 4D technology® product.

3.1 Product dimensions

- Sonico® EDGE is available as a compact version. The signal converter including the display is directly mounted onto the meter body. The meter head can be equipped with up to three independent external Near Field Communication (NFC) modules.
- Nominal sizes are DN50, 80, 100, 150, 200 & 300.
- Other nominal sizes and lengths on request.





Figure 1: Dimensions of sonico® EDGE with (right) and without (middle) external NFC modules

Nominal size		L (mm)	H (mm)	W (mm)	a (mm)	b (mm)	c1 (mm)	c2 (mm)	Weight (kg)
mm	inch								
50	2	200	220	165	110	122	152	177	13
65	1.5	200	236	185	153	122	152	177	14
80	3	200	250	200	110	122	152	177	16
100	4	250	270	220	110	122	152	177	21
125	5	250	285	250	169	122	152	177	25
150	6	300	336	285	120	122	152	177	33
200	8	350	395	340	234	122	152	177	60
250	10	450	425	410	241	122	152	177	82
300	12	500	475	460	252	122	152	177	115

Table 1: Dimensions of sonico® EDGE meters

3.2 Product design



3.3 Seals

Three seals are placed on sonico® EDGE in order to protect it from tampering:

- Calibration seal attached to a screw connecting meter body to meter head. Breaking this seal invalidates any warranty or metrological certification.




Figure 2: Calibration seal

- The cap of the meter head acts as a seal protecting all electronics from manipulation. Breaking this seal invalidates any warranty or metrological certification.




Figure 3: Meter cap as seal for electronics

- Communication seal on the communication module lid. Can be removed in order to attach or exchange communication modules (see chapter 10.1).




Figure 4: Communication seal for modules

3.4 Applications

- Potable and raw water
- Water production and water supply, zone metering
- Irrigation
- Industrial flows (flow measurement, process optimization)

3.5 4D technology®

The 4D technology® signal processing is based on the patented Time Reversed Acoustic (TRA) ultrasonic technology and is characterized by a high signal-to-noise ratio.




Figure 5: Illustration of time of flight measurement principle

- Every single device is taught in standing water on the test bench.
- In standing water, the semi-dry transducers send an ultrasonic pulse through two paths and measure the resulting base signal:




Figure 6: Ultrasonic pulse sent in standing water




Figure 7: Meter-specific base signal received in standing water

- The base signal is inverted and saved in the microcontroller:




Figure 8: Time-reversed base signal forms the TRA reference signal

- This is how the TRA reference signal is created. It is made up of a signal as well as a single pulse and is similar to a melody.
- The TRA reference signal gives each meter its own DNA, which takes the material and assembly tolerances into account:




Figure 9: Every sonico® EDGE meter has an individual TRA signal

- During operation, the reference signal is sent and received in the flow and reverse flow direction.
- The two signals are now overlapped by digital means.
- The unique shape of the signal simplifies the detection of the amplitudes with respective timing in both directions.
- This enables the time shift of the two maximum amplitudes to be determined and the flow velocity and flow rate to be calculated.




Figure 10: The reference signals received with and against flow direction are overlapped

- Flow profile distortions are detected and compensated.

4 Incoming inspection

4.1 Scope of delivery



Notice

Inspect the packaging and the contents for damage or signs of rough handling. Report damage to the carrier and to the local office of the manufacturer. Check that the delivery is complete and agrees with the shipping documents and your order. If damages occurred or any items are missing, please contact GWF without delay and before proceeding with installation.

Scope of delivery

1. Sonico® EDGE flow meter
2. IP68 power cable connection included
3. Communication modules attached to the meter, depending on the order
4. Short installation guide
5. 1 pair of flange gaskets




Figure 11: Scope of delivery



Information

Keep original packaging for safe storage and transport.

Optional accessories

1. IR communication kit
 - a) Optohead holder
 - b) Optohead (optical communication device)
 - c) Charging cable for optohead




Figure 12: Optional accessories



Information

Assembly materials and tools are not part of this delivery.

4.2 Checklist incoming acceptance

See chapter 15.1.1.



Information

If one of the points in the checklist are not satisfied, please contact GWF. The full technical documentation and manual are available online on www.gwf.ch.

4.3 Nameplate



Information

Check the name plate to ensure that the device is delivered according to your order. You can do so by verifying serial number and version number on the name plate. Additionally, check for the correct supply voltage on the name plate.

The name plate (Figure 13) indicates important data for identification of the device.




Figure 13: Exemplary name plate (DN50 meter)

5 Storage / Transport

5.1 Storage

- Store the equipment in a dry and dust-free place.
- Do not store outdoors.
- It is recommended to avoid continuous exposure to direct sunlight.
- Store the device in its original packaging.
- Storage temperature: -25...+70 °C, ideally at 20 °C.

5.2 Transport



Warning – Bodily injury

Life-threatening danger due to suspended loads possibly falling.
Remaining under suspended loads is prohibited.



Warning – Risk of injury due to the sensor slipping

The meter's center of gravity may be higher than the harness' suspension points.
Make sure that the sensor does not slip or turn during transport.
Support the sensor laterally during transport.

- Do not lift the device by the attached communication modules.
- Do not lift the device by the display lid.
- Do not use lifting chains, only lifting straps wrapped around both meter body flanges.
- Do not lift the meter lopsided by one flange only.




Figure 14: Lifting instructions

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable.

- Packaging: cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by RESY symbol.



Getting Started – Installation and Mounting

6 Installation / Mounting



Notice

Be advised that possible mounting and connection errors and their effects are beyond our control. Therefore, the manufacturer cannot be held responsible for damages as a result of incorrect handling, installation, and maintenance of the equipment.

6.1 General requirements


The meter must be installed by a trained and instructed worker. Thereby the recognized standards of good practice must be respected (Refer to the instructions given in ISO 4064-5:2014).

The meters must be stored in a dry, cold, dust and germs free environment. Make sure that during the installation procedure all hygienic standards and recommendations are followed.

6.2 Installation conditions


- The meters' metrological performance depends on flow direction and meter orientation. Orientation can be selected to best suit the installation conditions.
- The flow direction (direction arrow) can already be fixed during production. Otherwise (default) the direction arrow is automatically determined by the meter after installation. As soon as the meter detects a flow, it automatically sets the direction arrow after 5 seconds at the latest and is displayed on the
- .
- Gaskets must not protrude into the pipeline or be misaligned.
- All meter settings and functions will be automatically and correctly activated once the measurement channel is completely filled with water.

Open feed or discharge may cause air in measuring channel:




- The meter does not need any straight inlet or outlet pipe sections, even with 90° bends or valves present.
- The meter must always be filled with water. Air in the pipe will result in an error.


Elbows (caution, measuring channel must not contain air):




Valves:



Pumps:



Mounting position independent of meter orientation:



6.3 Environment and process requirements

- For correct flow measurements, the meter should always be filled with water. Non-wetted sensors show loss of signal. Although this will not cause damage to the meter, the meter will not measure flow and display the empty pipe alarm.
- It is recommended to protect the meter from direct sunlight. It is recommended to keep the lid closed.
- Operating temperature of medium. Depending on meter type: T30 = 0.1 to +30 °C, T50 = 0.1 to +50 °C. Temperature class indicated on the nameplate, see [Figure 13](#).
- The environmental temperature must be within -25 °C and 70 °C.
- Pressure: Please ensure that the meter strictly operates within the pressure rating printed on the nameplate (see [Figure 13](#)).
- Sonico® EDGE is classified according to 2014/32/EU (MID) in the mechanical environment class M2 (significant or high levels of vibration and shock) and in the electromagnetic environment class E2.

6.4 Checklist installation preparation

See chapter [15.1.2](#).

6.5 Mounting



Notice

Please take care to use the proper gasket to prevent damaging the liner of the flow meter. In general, the use of spiral wound gaskets is not advised, as it could severely damage the liner of the flow meter.

Step 1: Remove the meter from the packaging.

Step 2: Install the meter according to the most suitable LCD orientation and tightening the bolts as indicated in chapter [6.5.1](#)

6.5.1 Torques and pressures




Figure 15: Schematic illustration of bolt tightening to flanges

Tightening of bolts:

- Always tighten the bolts uniformly and in diagonally opposite sequence.
- Do not exceed the maximum torque value.
- **Step 1:** Apply approx. 50 % of max. torque given in [Table 2](#).
- **Step 2:** Apply approx. 80 % of max. torque given in [Table 2](#).
- **Step 3:** Apply 100 % of max. torque given in [Table 2](#).

Recommended torque values are shown in [Table 2](#). Parameters strongly depend on type of bolt and amount of grease used.

DN (mm)	PN16	
	Nm	ft-lbs
50	120	90
65	120	90
80	120	90
100	120	90
125	120	90
150	250	180
200	250	180
250	250	180
300	250	180

Table 2: Recommended torque values

7 Electrical connection



Warning

All work on electrical connections may only be carried out with the power disconnected. Take note of the correct supply voltage indicated on the nameplate.

Improper connection can cause injury or death. The electrical connection must be carried out by a certified electrician.

Observe the national regulations for electrical installations! By handling products which are supplied by electrical voltage, the valid IEC instructions, especially IEC 60364, IEC 61558, IEC 60335, IEC 60598-1 and IEC 60065, must be observed.

Before opening the instrument, pull off the main plug and make sure that the instrument is without power supply. Conducting cables or conductors which are connected to the instrument must be checked continuously for isolation faults or sites of fractures. If a fault is found in the supply line the instrument must be disconnected from the main plug till the defective line has been replaced.

Before setting into operation generally check if the instrument is suitable for the field of application. If there is any doubt, you must inquire with a technical expert or the manufacturer.

7.1 Checklist electrical connection: tools and requirements

See chapter 15.1.3.

7.2 Power supply meter



Caution

Before connecting or disconnecting the cable, be sure the power is switched off.

All cables must be installed in order to protect cables from mechanical destruction. Mount the cables firmly to the wall, without any loops and cross-overs and in sufficient distance to moving parts to avoid accidents caused by stumbling.

Voltage supply: 9 - 36 V DC \pm 10 % (26.4 V)

$I_{\text{supply}} @ 24 \text{ V DC}$: 100...300 mA whilst the internal accumulator is being charged


$I_{\text{supply}} @ 24 \text{ V DC}$: 20...50 mA once the internal accumulator is fully charged

7.2.1 Technical specification for power transformer

Min. voltage output/-current: 24 V/200 mA

Max. allowed ripple: 200 mV peak-peak

7.2.2 Power cable and joint connection



1	Sonico® EDGE water meter
2	External power supply cable [3 m]
3	IP68 cable connector

Figure 16: Electrical connection scheme and part list of sonico® EDGE meter power supply

3 m of power cable are connected to the sonico® EDGE measuring adapter upon delivery. Make sure to provide suitable additional length of cable and connect via the included IP68 cable connection.



Warning

The user is responsible for ensuring EMC Protection for any electrical components connected to the meter that were not included in the scope of delivery.

7.3 Checklist electrical connection: final inspection

See chapter 15.1.4.

8 Display and meter activation

8.1 Display symbols

Sonico® EDGE is equipped with an integrated LCD showing several symbols and two number fields. The larger segment on top of the display is a 10-digit field and the smaller one on the bottom of the display is a 7-digit field.




Figure 17: Scheme of all segments visible on sonico® EDGE display

Location of information in normal operating mode:

- The upper, 10-digit field depicts the total volume.
- The lower, 7-digit field shows the current flowrate.
- The + sign in front of the flowrate indicates flow in forward direction with respect to the defined forward direction.
- The defined direction is shown by the arrow in the bottom left part of the display.

Symbol	Meaning
T1	Tariff zone 1
T2	Tariff zone 2
Test	Meter test bench mode
	Alarm flag, error occurred
	Radio interface connected (not activated yet)
	Arrow indicates the defined flow direction
	No external power supply

Table 3: Symbols of the sonico® display

All LCD units, i.e. volume and flow units, can be configured by GWF according to the specific order.

As a standard factory setting, three decimals are shown for volume in the larger 10-digit display field, as shown in [Figure 18](#).



Figure 18: Standard display of volume with three decimals

8.2 Meter activation

After connecting the meter to an external power supply, sonico® EDGE is ready for activation and measurement.

Step 1: Check meter display

In a dry pipe, the meter will display the following information:

- Latest measured total volume in the volume field.
- The alarm flag (indicating an empty pipe).
- Periodically, the error code "Air in pipe" E_L0001 will be display in the lower 7-digit field.

Step 2: Fill the pipe with water

Once successfully installed, open the upstream valve to fill the pipe. The alarm flag shown in the display disappears as soon as the meter detects water.

Step 3: Flow direction

To activate the “flow direction arrow”, a flowrate above the configurable cut-off flowrate value (e.g. 25 l/h) must be detected for at least 10 measurement cycles (approx. 5s). Afterwards, the measured flow direction is automatically set as the forward flowrate direction. The arrow direction is set and stored permanently. If activated in the meter settings (standard factory settings), any flow in the opposite direction will be counted as reverse volume.

**Information**

The meter does not register the volume if the averaged flow rate is below its cut-off flow rate (see chapter 13.1).

After a flow has been measured by the device, advanced analytical functions such as data logging and leak detection become active and are assigned to the respective data fields.

8.3 Default display sequence

When the meter is running, the following reoccurring sequence in the display will be shown:

1. Cumulative volume in the upper number field and current flowrate in the lower number field (min. 30 s)
2. All segments on, i.e. all symbols lit up as shown in [Figure 17](#) (min. 1 s)
3. All segments off, i.e. blank display (min. 1 s)
4. Forward volume in the upper number field as shown [Figure 19](#).
5. Reverse volume in the upper number field as shown [Figure 20](#).
6. If an error occurred: Warning symbol and error code starting with the letter “E” in the lower number field (min. 1 s). Error codes are described in chapter 11. An example of the error message for an empty pipe is shown in [Fehler! Verweisquelle konnte nicht gefunden werden..](#)




Figure 19: Exemplary screenshot of forward flow volume register as shown in display sequence



Figure 20: Exemplary screenshot of back flow volume register as shown in display sequence

In addition to the default display sequence, the firmware checksums and versions are periodically displayed. Sonico® EDGE incorporates two firmware parts, one for metrological characteristics, the other for LCD. Every 5 min. the checksum and version of first the metrological firmware and then the LCD firmware are displayed.

The checksum is shown in the upper number field; the version number is displayed in the lower number field. The version number will be presented in 4 digits, e.g. firmware version 2.0 will be presented as 0200 and version 2.47 as 0247.

8.4 Test bench mode

For calibration and verification measurements, the sonico® water meter can be set into test bench mode using sonico® LIFE application software. The activation of the test bench mode is password protected. As soon as the test bench mode is activated, "Test" is shown in the display. The volume register shows one more decimal, thus 0.1 l resolution by default. The test bench mode can be set back to operation or other modes manually using the sonico® application software.




Figure 21: Example of display during activated test bench mode.



All Things Software – IR Interface and Communication

9 IR interface (optohead) and sonico® LIFE application

In addition to the NFC interfaces, the IR interface and an optical reading head can be used to communicate with the sonico® EDGE counter. This “optohead” can be connected to an Android tablet via Bluetooth interface. With the sonico® LIFE application software, the event history can be displayed and metrologically irrelevant parameters can be configured.

9.1 Activation of IR interface

The Bluetooth optical head contains an IR diode on one side and the Bluetooth interface for communication with a Bluetooth Android tablet on the other.



Figure 22: Optohead (IR to Bluetooth)

Before using the optohead for the first time, charge it with the provided power supply cable. Make sure to switch off the device during charging.

The optohead can be plugged into a plastic cover with the infrared diode facing the meter display. To connect the optohead to the meter, insert it into the plastic holding cover contained in your order. Open the meter display lid and push the plastic cover containing the optohead onto the display cavity until the snaps fit in. Mind that the meter display lid needs to be at a 90° angle to the meter display in order to snap-in the cover, see [Figure 24](#).




Figure 23: Connecting the optohead in the holding cover to the meter




Figure 24: Optohead fitted on the meter. Display lid is in a 90° angle to the meter display

Once the optical device is placed on the meter, switch on the reading head. The green status LED lights indicate that the optohead is ready for operation. Activate the Bluetooth function of your terminal device and connect to the optical interface.

When choosing to connect to the optohead with your terminal device, a password has to be entered. The factory-set Bluetooth password for the optohead is 0000.



Information

If the connection to the meter cannot be established or if there is an error message using sonico® LIFE, please turn the optohead by 45° inside the holder and try again to connect. Disturbance by strong external lights do may influence the IR connection to the meter and shall be avoided.

9.2 Sonico® LIFE to enable legal meter information

The sonico® EDGE meter can be connected to an Android based device using the optical reading head and sonico® LIFE as described above. Sonico® LIFE can be used to access the legal meter functions and enables access to the history of the meter's legal metrology. This includes the firmware version, firmware update history and the event history.

The legal application also allows meter firmware updates. The sonico® EDGE legally relevant firmware can be updated three times in total. Unsuccessful attempts also count as an update. Furthermore, the device-specific key can be set with the legal application.

The GWF sonico® LIFE application including the legal function can be downloaded from google play store.

Updates of legal relevant firmware require approval from the legal body.

9.3 Removal of optohead

To remove the optohead cover, push the display lid back until the cover releases.




Figure 25: Removal of optohead cover by pushing back display lid

Switch off the optohead after each communication session in order to save battery life of the device.

10 Communication modules

By default, if communication modules are ordered together with the meter, they will be attached to the respective NFC port upon delivery.



Information

Once a communication module is attached to the meter and connected to its endpoint, the radio symbol on the meter display is activated and the meter starts communicating.

As a standard, 3 m of power cable are connected to the sonico® EDGE communication modules upon delivery. Make sure to provide suitable additional length of cable and connect via the included IP68 cable connection.

10.1 Exchanging or adding communication modules

The three independent NFC communication slots of sonico® EDGE are designed such that communication modules can be readily exchanged or added during operation.

Step 1: Remove communication seal and open module lid, as shown in [Figure 26](#).

Using a screwdriver, destroy and remove the red communication seal on the meter head. Then push the screwdriver into the opening and slightly outward to unlock the snap-in connection holding the module cover in place. While pushing the screwdriver outward, the module lid can be opened by tilting it upwards from the backside of the meter.




Figure 26: Breaking of communication seal and lifting of module lid

Step 2: Exchange protective cover on the module lid, see [Figure 27](#).

If additional NFC modules shall be added to the meter, the protective cover on the module lid needs to be exchanged. Remove the cover from the opened module lid by pulling it outward as shown in [Figure 27](#). Separate module covers for one or two slots are available. If one module shall be placed on the meter, the two remaining slots need to be covered. If two modules are placed on the meter, only one remaining slot needs to be covered. Connect the suitable protective cover to the module lid such that the NFC slots on which a module will be placed remain uncovered. The cover will click in place when pushed onto the module lid.




Figure 27: Exchanging protective cover in order to add a new module

Step 3: Mounting of a communication module, as shown in **Figure 28**.

The communication module can now be connected to the meter. The pulse module can be connected at both outer slots (no. 1 or 3) on the meter NFC interface. The module slot numbers 1-3 are engraved on the module lid. Insert the pulse module to slot 1 or 3 by pushing it down and connecting it to the two hooks placed in the frame. Now slide the module forward horizontally towards the front of the meter. The module should click into place and be firmly connected to the meter. Close the module lid and finally use a new communication seal.




Figure 28: Inserting module, pushing it into place and closing the module lid

**Caution**

After plug-in of the NFC modules, do not put any other NFC device near the device which may disturb the communication between the device and the modules.

10.2 Connection schematics communication modules

The detailed connection schematics for the NFC communication modules (Pulse, 4-20mA, ECO and Modbus) can be found online at the following link or QR code:





Module	Link to website	QR Link
Pulse module	https://productfinder.gwf.ch/sonico-puls-modul	
4-20mA module	https://productfinder.gwf.ch/sonico-4-20-ma-modul	
ECO module	https://productfinder.gwf.ch/sonico-eco-e1-e2-modul	
Modbus module	https://productfinder.gwf.ch/modbus-module	

Table 4: Connection schematics communication modules



Houston, we have a problem – Alarms and troubleshooting

11 Error codes and troubleshooting

If the alarm flag appears, an error code will be shown in the display sequence as explained in chapter 8.3. The default threshold values of the respective errors are given in the table below. These values are factory set by the manufacturer. If an error message does not automatically reset (see table), it will have to be reset by a GWF specialist. This is especially important for the legally relevant errors “Air in Water” and “Internal Error (Malfunction)”. Please contact your local representative for assistance.

Error Type	Error Code	Description*	Recommended Actions	Automatic Reset
Air in Water	E_L0002	Air in Water detected (Bubbles or Empty Pipe). This alarm will be reset as soon as the pipe is completely full, or the occurrence of bubbles disappears.	Flush pipe Check installation position and switch if necessary Check if cavitation occurred and reduce max. flow rate	Yes Alarm resets when no more air is detected
Burst Pipe	E_C0004	Max. defined flow rate (1.5 xQ4*) exceeded.	Check piping system	Yes Auto reset: 1h
Leak detection	E_C0002	Flow rate never below min. set value.	Check piping system and valves	Yes Auto reset: 1h
Reverse Flow	E_C0001	Reverse flow measured	Check correct installation. Change orientation of the meter	No
No Usage	E_C0008	Zero Flow over defined time (100d*) detected	Check piping system and valves Dismount meter and check for obstructions in the pipe, measurement channel or on the sensors Contact manufacturer for maintenance	Yes Auto reset: 1d

Water Temperature	E_C0010 E_L0010	Medium temperature is outside of a pre-determined temperature range (5 °C to 60 °C*) during a pre-determined time interval of 120 min.	Increase or reduce water temperature If integrated temperature sensor may have failed, contact manufacturer	No
Ambient Temperature	E_C0020 E_L0008	Ambient temperature is outside of a pre-determined temperature range (-10°C °C to 70 °C*) during a pre-determined time interval of 120 min.	Protect installation from direct sunlight or cold temperatures and regulate ambient temperature	No
No External Supply	E_C0040	External power disconnected	Check cables, fuses and power supply Check voltage level (must be from 19.2 to 26.4 V DC)	No
Internal Error (Malfunction)	E_L0001	General internal error	Contact GWF for assistance and reset	No
Sensor Error	E_L0020	Sensor failure	Contact GWF for assistance	No
Sensor Error	E_L0040	External flash malfunction	Contact GWF for assistance	No

Table 5: Error types and codes and their standard thresholds

* All parameters are default factory alarm threshold values.



We're almost done – After Use and Details

12 Dismounting and disposal

12.1 Dismounting



Warning

Disconnect power before dismounting the device.

- Check if the pipe is empty.
- Disconnect meter and communication modules from power supply.
- Loosen the bolts and carefully remove meter from pipe.
- Remove flange gaskets.

12.2 Disposal



Caution

Dispose the device in compliance with your country's legal and valid regulations for the disposal of electronic and electrical appliances. Correct disposal avoids negative effects on public health and the environment and ensures recycling of valuable raw materials.



This symbol indicates that the directive 2012/19/EU (WEEE) on waste and electronic equipment requirements shall be observed upon disposal of the device.

12.3 Recycling

This product contains a lithium ion battery. In order to protect the environment, this device may not be disposed in regular household waste after the end of its lifetime. Any local and national regulations for environmental protection shall be considered.

12.3.1 Product recycling and disposal (Europe only)



Electrical equipment marked with the above symbol may not be disposed of in European public disposal systems as of 12 August 2005. According to European local and national regulations (EU Directive 2012/19/EU), European electrical equipment users may return old or end-of-life equipment to the manufacturer for disposal or recycling at no charge. GWF is committed to minimize the risk of any environmental damage or pollution caused by any of its products.



Information

For return or recycling, please contact GWF or your local supplier for detailed instructions.

12.4 Return / Repair

Please follow the following instructions in case the device shall be returned to GWF for repair or inspection:

- Download the return form on the official GWF website in the support section.
- Fill in the form and include the completed form with your return shipment.
- Send the device with proper declaration of hazardous material.
A suitable warning label according to 'UN3481 PI 967 Sec II' must be attached to the packaging and remain visible on the outside of the package.
- Pack the meter safely, ideally by using the original packing.
- Send the parcel to GWF, Obergrundstrasse 119, 6005 Lucerne, Switzerland, for repair.

13 Technical data and certification

13.1 Metrological data

Nominal flow rate	DN	mm	50	65	80	100	125	150	200	250	300
Q3/ Q1			1000	1000	1000	1000	1000	1000	1000	1000	1000
Starting flow rate	Q _{start}	l/h	25	40	50	80	150	200	300	450	600
	V _{start}	m/s	0.0047	0.0053	0.0042	0.0042	0.0050	0.0045	0.0040	0.0060	0.0050
Minimum flow rate ± 5 %	Q1	m ³ /h	0.04	0.063	0.1	0.16	0.16	0.4	0.63	0.63	1
	V1	m/s	0.0076	0.0084	0.0084	0.0083	0.0083	0.0089	0.0084	0.0084	0.0084
Transitional flow rate ± 2 %	Q2	m ³ /h	0.064	0.101	0.16	0.256	0.256	0.64	1	1	1.6
	V2	m/s	0.012	0.013	0.013	0.013	0.013	0.014	0.013	0.013	0.013
Nominal flow rate ± 2 %	Q3	m ³ /h	40	63	100	160	160	400	630	630	1000
	V3	m/s	7.57	8.39	8.41	8.35	8.35	8.91	8.37	8.37	8.35
Overload flow rate	Q4	m ³ /h	50	75.6	125	200	200	500	787.5	787.5	1250
	V4	m/s	9.47	10.06	10.51	10.44	10.44	11.14	10.46	10.46	10.44
Maximal flow rate	Q _{max}	m ³ /h	90	140	200	300	300	600	1100	1100	2000
	V _{max}	m/s	17.04	18.63	16.82	15.66	15.66	13.37	14.61	14.61	16.71
Nominal pressure	PN	bar	16	16	16	16	16	16	16	16	16

Table 6: Metrological data of sonico® EDGE flow meters

13.2 Environmental specifications and certification

- Mechanical Environmental Class MI-001: M2; OIML R49: M2
- Electromagnetic Environmental Class MI-001: E2; OIML R49: E2
- Ambient storage temperature -20 °C to +70 °C
- Ambient operating temperature -20 °C to +70 °C
- Protection class IP68 according to EN 60529
- Protection against EMC levels according to ISO 4064

All relevant conformity certificates can be downloaded from the GWF website (www.gwf.ch) in the product finder section.

14 Spare parts and accessories

14.1 Available accessories

- IR communication kit including optohead, optohead holding frame and charging cable.

14.2 Communication modules

Communication modules as a spare part can be ordered directly from GWF. Please contact your local GWF representative for further technical information. The exchange or additional installation of communication modules to a sonico® EDGE meter is described in chapter 10.1.




14.3 Spare parts

- Flange gaskets
- Communication seal as described in chapter 3.3
- Display lid
- Module lid and module protective cover
- Flange connection bolts

15 Annex

15.1 Checklists

15.1.1 Checklist incoming acceptance ←

<p>Is the delivery undamaged?</p>	
<p>Does the order information on the packaging correspond to the delivery note?</p> <p>Do the details on the meter nameplate match the delivery note and your order?</p>	
<p>Is the scope of delivery complete, including any accessories?</p>	

15.1.2 Checklist installation preparation ←

Required tools	
Two spanners for the corresponding size of bolts	
Wrench for cable glands	
Torque wrench for installing flow meter in pipeline	
Optionally: Hoisting devices	
Check the following:	
Are the gaskets correctly aligned with the flange?	
Are water and environmental temperatures within specifications?	
Is the pressure rating corresponding to the one printed on the meter body?	

15.1.3 Checklist electrical connection: tools and requirements ←

Required tools	
Sonico® power supply cable extension	
Screwdriver	
Wire stripper	
When using stranded cables: Crimper for wire end ferrule	
Check the following:	
Is your power supply cable in accordance with federal/national regulations and suitable for min. and max. temperatures to be expected?	

15.1.4 Checklist electrical connection: final inspection ←

Check the following:	
Are transmitters, cables, sensors and cable glands undamaged?	
Is the housing properly fitted, clean and undamaged?	
Are all cable glands tightened?	
Are the mounted cables strain relieved and unbent?	

