



MULTICAL® 303





MULTICAL® 303



> 60 °C

At a media temperature higher than 60 °C, the flow sensor should be shielded from unintended contact.



16/25 bar

When working on the flow sensor in the installation, there is a risk of outflow of (hot) water under pressure.



Contents



In general

04



Information

05



Mounting of flow sensor

06



Mounting of temperature sensors

10



Mounting of calculator

16



Information codes "INFO"

18



Voltage supply

20



Testing of function

21



User guide

23




In general



https://guides.kamstrup.com/userguides/gb_mc303.htm



<https://www.kamstrup.com/en-en/heat-solutions/meters-devices/meters/multical-303/documents>



<https://www.kamstrup.com/>



Information



MID ✓ EN 1434 ✓
 θ : 2 °C...180 °C $\Delta\theta$: 3K...178K ✓

DK-BEK 1178 ✓ EN 1434 ✓
 θ : 2 °C...180 °C $\Delta\theta$: 3K...178K ✓

θ_q : 2°C...130°C ✓

The meter's approvals and temperature area for heat and cooling measurements [E1 and E3], respectively. This data can also be found on the meter's front.



E1 ✓

M1 ✓ M2 ✓

5°C...55°C ✓


IP 65 ✓

IP 68 ✓


The meter's environmental and mechanical classes. The meter must be mounted indoors in the temperature area of 5 °C...55 °C. The meter's signal cables should be drawn at least 25 cm away from other installations. The meter has the mechanical classes 1 and 2.







Mounting of flow sensor



- PN16, PS16 ✓
- PN25, PS25 ✓
- PN16/PN25, PS25 ✓



- qp: XX m³/h ✓
- qi: XX l/h ✓
- qs: XX m³/h ✓







Pressure stage and flow data of the meter. The pressure stage of the provided accessories follows the markings on the meter. Up to and including DN80, PN16 and PN25 are connection compatible. The DN measurements of the meter must fit the installation, but one dimension up or down in size is also acceptable.



Mounting of flow sensor



2/4



Preparations before mounting. Before mounting the flow sensor, protection wafers are removed; remember gasket when mounting


Check the meter display for correct placement of the flow sensor in either inlet or outlet, depending on the meter setup. In the same way, the mounting of the flow sensor in the correct flow direction is ensured, which is indicated by an arrow on the flow sensor.



Mounting of flow sensor



3/4




- A** Recommended position.
- B** Recommended position.
- C** Unacceptable position due to risk of air build-up.
- D** Acceptable position in closed systems.
- E** Ought not to be placed immediately after a valve, with the exception of block valves (ball valve type) which must be fully open when not used for blocking.
- F** Ought not to be placed immediately before or after a pump.
- G** Ought not to be placed immediately after a double bend in two planes.



Mounting of flow sensor



4/4




The flow sensor can be mounted horizontally, vertically or at an angle. In case of cooling installations, it is recommended to mount the flow sensor at an angle of 0°.





qp 0.6...2.5 m³/h



34



Directions marked with  can be used if the prerequisites below are met:


-  District heating water must be pure and not contain impurities. In a given case, impurities can cover the transducers of the flow sensors, which affects their abilities to register and send the ultrasound signal.




Mounting of temperature sensors



1/6



Mounting the temperature sensor. t1 is always mounted in inlet, whereas t2 is always mounted in outlet. t1 and t2 appear from the temperature sensor label.



In addition to the marking on the label, t1 is marked with a laser engraved grey ring on the cable for quick indication.



Mounting of temperature sensors



2/6



[x1] t1

[x2] t2

[x0] t3

| | t1 | t2 | t3 |
|--|----|----|----|
| | | | |
| | | | |
| | | | |

Depending on the type of the temperature sensor, there are, in addition to the marking of t1, t2 and t3, colour and bar codes for quick indication. t1 is always marked with a black line, whereas t2 is always marked with two black lines. t3 is never marked with lines but is always marked with grey. t3 can be mounted in both inlet or outlet.

Heat: t1 is marked with red colour and a black line; t2 is marked with blue colour and two black lines; t3 has no marking.

Cooling: t1 is marked with blue colour and a black line; t2 is marked with red colour and two black lines; t3 has no marking.



Heat/Cooling: t1 is marked with both red and blue colours and a black line; t2 is marked with both red and blue colours and two black lines; t3 has no marking.





Mounting of temperature sensors



3/6



Mounting/immersion depth of the temperature sensor. The sensor must as a minimum cross the centre of the pipe to ensure correct temperature measurement.



Be aware of the sensor's direction in the installation.

Cooling: To avoid that condensation forms on the sensor, the sensor should be mounted with the cable pointing downwards or to the side so that drops of water cannot get into the sensor.

Heat: All directions are acceptable.



Mounting of temperature sensors



4/6



PN16

PN25



Approved pressure class of the temperature sensor. Temperature sensors are approved for PN16 and PN25.



| q _p | DN | G | DS 27,5 | ø5.0 mm/ ø5.2 mm |
|----------------|----|-----|---------|---------------------|
| 0.6-1.5 | 15 | G¾B | X | X |
| 1.5-2.5 | 20 | G1B | X | X |


Temperature sensor and flow sensor compatibility. The size of the flow sensor determines which temperature sensors you can use and how to mount them.



Mounting of temperature sensors



5/6



Mounting of $\varnothing 5.0/\varnothing 5.2$ with composite union nut. When mounting a sensor in a ball valve that does not follow EN1434-2:2022, an O-ring is inserted using the mounting tool [3130-287] as well as the provided spacer ring before the sensor is installed in the valve. When mounting a sensor in a flow sensor, nipples and ball valves that follow EN1434-2:2022, an O-ring is inserted using the mounting tool [3130-287] before the sensor is mounted.



The tightening of the sensor is done by hand.





Mounting of temperature sensors



6/6



Shortening of temperature sensor cables. It is not allowed to shorten the cables of the temperature sensor.





Cable insulation of the temperature sensor. If the temperature sensor cables are bent in connection with the mounting, a bending radius of at least 10 mm must be ensured.



Mounting of calculator



1/2



$q_p \leq 2.5 \text{ m}^3/\text{h}$ ✓ $\theta_q > 90 \text{ }^\circ\text{C}$ ✓ $\theta_q < \text{RT}$ ✓




The calculator can with advantage be mounted on the flow sensor in installations in which the medium temperature is higher than the ambient temperature but lower than $90 \text{ }^\circ\text{C}$. Alternatively, the calculator can be mounted to a wall. For wall mounting, use the wall bracket (3026655).









Mounting of calculator



2/2




In cooling installations, the calculator must be placed on the wall above the flow sensor to avoid condensation problems.




Mounting of installation seals. To protect against fraud on the meter installation, installation seals must be mounted. The sealing of the installation can, for example, be done by means of wire and seal, sealing label or a combination of these.



Information codes "INFO"



1/2



In case of errors in the meter, the info code appears in the meter display. The various info codes are shown in the table below. For further details, see the technical description.

| Info | t1 | t2 | 0 | V1 | 0 | In-A | In-B | |
|------|----|----|---|----|---|------|------|-------------|
| 1 | | | | | | | | |
| 2 | | | | | | | | |
| | 1 | | | | | | | t1 > 185 °C |
| | | 1 | | | | | | t2 > 185 °C |
| | 2 | | | | | | | t1 < 0 °C |



Information codes "INFO"



2/2

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------|----|----|---|----|---|------|------|
| Info | t1 | t2 | 0 | V1 | 0 | In-A | In-B |
| | | 2 | | | | | |
| | | | | | | | |
| | 9 | 9 | | | | | |
| | | | | 3 | | | |
| | | | | 4 | | | |
| | | | | 6 | | | |

$t2 < 0\text{ }^{\circ}\text{C}$

$\Delta t (t1 - t2) = \text{X}$





V1:

V1:

$V1 > q_s$



Voltage supply







The meter's battery must neither be charged nor short-circuited.

Batteries are disposed of by handing them in for approved destruction of lithium batteries, e.g. to Kamstrup A/S.



Testing of function



After completed installation, it is checked that the meter functions correctly. Open thermoregulators and valves to establish water flow through the system. Then check if reliable values are shown for t1, t2 and flow.



The central part of the image features a large rounded rectangle containing a hand holding a magnifying glass over a smart meter display. A play button icon is overlaid on the bottom right of this rectangle. Surrounding this central area are several smaller digital display icons:

- Top center: Two temperature displays. The left one shows $t12$ with a value of 42.68 and a unit $^{\circ}C$. The right one shows $t2$ with a value of 34.21 and a unit $^{\circ}C$. Below each is a thermometer icon and a small circle with the corresponding $t1$ or $t2$ label.
- Left side (top to bottom):
 - A display showing 316 with a unit $\frac{m^3}{h}$ and a flow icon.
 - A display showing 15.5 with a unit kW and a power icon.
 - An "INFO" icon with a warning triangle.
- Right side (top to bottom):
 - A display showing $t1$ with a value of 76.89 and a unit $^{\circ}C$, with a house icon below.
 - A display showing 0008760 with a unit h and a clock icon.
 - A display showing 00289.23 with a unit m^3 and a refresh icon.
- Bottom center (left to right):
 - A display showing 123 with a unit N° and a meter icon.
 - A large display showing E1 with a value of 0014258 and a unit kWh , with a red icon containing three wavy lines below it.
 - A display showing E3 with a value of 0003.106 and a unit MWh , with a blue snowflake icon below it.



DDD = 310

https://guides.kamstrup.com/userguides/gb_mc303.htm



MULTICAL® 303

